# BioLegend

# **LEGENDplex™** Multi-Analyte Flow Assay Kit

**Cat. No. 740502, Human Macrophage/Microglia Panel (13-plex) with Filter Plate** Cat. No. 740503, Human Macrophage/Microglia Panel (13-plex) with V-bottom Plate

Cat. No. 740504, Human M1 Macrophage Panel (8-plex) with Filter Plate Cat. No. 740505, Human M1 Macrophage Panel (8-plex) with V-bottom Plate Cat. No. 740506, Human M2 Macrophage Panel (6-plex) with Filter Plate Cat. No. 740507, Human M2 Macrophage Panel (6-plex) with V-bottom Plate Cat. No. 740508, Human M1/M2 Macrophage Panel (10-plex) with Filter Plate Cat. No. 740509, Human M1/M2 Macrophage Panel (10-plex) with V-bottom Plate

Please read the entire manual before running the assay.

BioLegend.com

#### It is highly recommended that this manual be read in its entirety before using this product. Do not use this kit beyond the expiration date.

For Research Purposes Only. Not for use in diagnostic or therapeutic procedures. Purchase does not include or carry the right to resell or transfer this product either as a stand-alone product or as a component of another product. Any use of this product other than the permitted use without the express written authorization of BioLegend is strictly prohibited.

Table of ContentsPa	age
Chapter 1: KIT DESCRIPTION	. 3
Introduction	3
Principle of the Assay	4
Beads Usage	4
Storage Information	6
Materials Supplied	6
Materials to be Provided by the End-User	. 8
Precautions	9
Chapter 2: ASSAY PREPARATION	10
Sample Collection and Handling	10
Reagent Preparation	. 10
Standard Preparation	. 11
Sample Dilution	. 12
Chapter 3: ASSAY PROCEDURE	. 13
Performing the Assay Using a Filter Plate	. 13
Performing the Assay Using a V- bottom Plate	16
Chapter 4: FLOW CYTOMETER SETUP	19
Chapter 5: DATA ACQUISITION AND ANALYSIS	• 19
Data Acquisition	. 19
Data Analysis	• 20
Chapter 6: ASSAY CHARACTERIZATION	• 21
Representative Standard Curve	. 21
Assay Sensitivity	· 21
Cross-Reactivity	22
Accuracy	• 22
Linearity of Dilution	. 23

LEGENDplex™ Human Macrophage/Microglia Panel	
Intra-Assay Precision	23
Inter-Assay Precision	24
Biological Samples	25
TROUBLESHOOTING	29
PLATE MAP	33

.

#### Chapter 1: KIT DESCRIPTION

#### Introduction

Macrophages are produced by differentiation of monocytes in response to an infection or tissue damage. Their primary function is to recognize, engulf, and destroy target cells including pathogens, dying or dead cells and cellular debris. Like dendritic cells, macrophages are also professional antigen presenting cells that play a crucial role in initiating an immune response. Macrophages secrete an array of cytokines which aid in host defense, tissue repair, and immunoregulation. Macrophages can be divided into multiple subtypes based on different functions. Inflammation-encouraging M1 macrophages produce proinflammatory cytokines, such as IL-12p70, TNF- $\alpha$ , IL-6, IL-1 $\beta$ , IL-12p40, IL-23, IFN- $\gamma$ , and IP-10. Anti-inflammatory and tissue-repairing M2 macophages decrease immune reactions and promote tissue repair by releasing a different set of factors, such as IL-4, IL-10, IL-6, Arginase, TARC, and IL-1RA.

Due to their important roles in immune responses, macrophages are critically involved in a variety of human inflammatory disorders, such as sepsis-related multiple organ dysfunction/failure, microbial infection, acute injuries, neurodegenerative disorders, cancer, cardiovascular, and autoimmune diseases. Measuring the mediators of proinflammation and anti-inflammation produced by macrophages may help not only in understanding the fundamental functions of macrophages, but also in finding the mechanisms of various pathological processes.

The LEGENDplex<sup>TM</sup> Human Macrophage/Microglia Panel (13-plex) is a beadbased multiplex assay panel, using fluorescence-encoded beads suitable for use on various flow cytometers. It allows for simultaneous quantification of 13 key targets involved in monocyte differentiation and macrophage functions including Arginase, IFN-y, IL-10, IL-12(p40), IL-12(p70), IL-1RA, IL-1 $\beta$ , IL-23, IL-4, IL-6, IP-10, TARC, and TNF- $\alpha$ . This assay panel provides higher detection sensitivity and broader dynamic range than traditional ELISA methods. The panel has been validated for use on cell culture supernatant, serum, and plasma samples.

The LEGENDplex<sup>™</sup> Human Macrophage/Microglia Panel is designed to allow flexible customization within the panel. It can also be divided into subpanels such as:

LEGENDplex<sup>™</sup> Human M1 Macrophage Panel (8-plex) LEGENDplex<sup>™</sup> Human M2 Macrophage Panel (6-plex) LEGENDplex<sup>™</sup> Human M1/M2 Macrophage Panel (10-plex)

Please visit **www.biolegend.com/legendplex** for more information on how to mix and match within the panel.

#### Principle of the Assay

BioLegend's LEGENDplex<sup>™</sup> assays are bead-based immunoassays using the same basic principle as sandwich immunoassays.


Beads are differentiated by size and internal fluorescence intensities. Each bead set is conjugated with a specific antibody on its surface and serves as the capture beads for that particular analyte. When a selected panel of capture beads is mixed and incubated with a sample containing target analytes specific to the capture antibodies, each analyte will bind to its specific capture beads. After washing, a biotinylated detection antibody cocktail is added, and each detection antibody in the cocktail will bind to its specific analyte bound on the capture beads, thus forming capture bead-analyte-detection antibody sandwiches. Streptavidin-phycoerythrin (SA-PE) is subsequently added, which will bind to the biotinylated detection antibodies, providing fluorescent signal intensities in proportion to the amount of bound analytes.

Since the beads are differentiated by size and internal fluorescence intensity on a flow cytometer, analyte-specific populations can be segregated and PE fluorescent signal quantified. The concentration of a particular analyte is determined using a standard curve generated in the same assay.

#### Beads Usage


The Human Macrophage/Microglia Panel uses two sets of beads. Each set has a unique size that can be identified based on their forward scatter (FSC) and side scatter (SSC) profiles (Beads A and Beads B, Figure 1). Each bead set can be further resolved based on their internal fluorescence intensities. The internal dye can be detected using FL3, FL4, or APC channel, depending on the type of flow cytometer used. The smaller Beads A consists of 6 bead populations and the larger Beads B consists of 7 bead populations (Figure 2-3).

Using a total of 13 bead populations distinguished by size and internal fluorescent dye, the Human Macrophage/Microglia Panel allows simultaneous detection of 13 cytokines in a single sample. Each analyte is associated with a particular bead set as indicated (Figures 2-3 and Table 1).




Beads A = smaller beads

Beads B = larger beads







For Beads usage in the panel, please refer to Table 1 below:

Target	Bead ID	Macrophage/ Microglia Panel Cat No. 740502 or 740503	M1 Panel Cat. No. 740504 or 740505	M2 Panel Cat. No. 740506 or 740507	M1/M2 Panel Cat. No. 740508 or 740509	Top Standard Concentrations
IL-12p70	A4	V	v		V	Note: The
TNF-α	A5	V	V		V	top standard
IL-6	A6	V	v	v	v	concentrations of analytes in
IL-4	A7	V		v		this panel were
IL-10	A8	V		v	v	set at various
ΙL-1β	A10	V	v		v	concentrations, but may be sub-
Arginase	B2	V		v		ject to change
TARC	B3	V		v	v	from lot to lot (please visit
IL-1RA	B4	V		v	V	biolegend.com/
IL-12p40	B5	V	v		V	en-us/legendplex
IL-23	B6	V	v		v	to download a lot-specific
IFN-γ	B7	V	v			certificate of
IP-10	B9	V	V		V	analysis).

Table 1. Panel Targets and Bead ID

\*Bead ID is used to associate a bead population to a particular analyte when using the LEGENDplex<sup>™</sup> data analysis software program. For further information regarding the use of the program please visit biolegend.com/en-us/legendplex.

#### **Storage Information**

Recommended storage for all original kit components is between 2°C and 8°C. DO NOT FREEZE Pre-mixed Beads, Detection Antibodies or SA-PE.

- Once the standards have been reconstituted, immediately transfer contents into polypropylene vials. DO NOT STORE RECONSTITUTED STAN-DARDS IN GLASS VIALS.
- Upon reconstitution, leftover standard and Matrix B6 should be stored at ≤-70°C for use within one month. Avoid multiple (>2) freeze-thaw cycles. Discard any leftover diluted standards.

#### Materials Supplied

The LEGENDplex<sup>™</sup> kit contains reagents for 100 tests, listed in the table below. When assayed in duplicate, this is enough for an 8-point standard curve and 40 samples.

Kit Components	Quantity	Volume	Part #
Setup Beads: PE Beads	1 vial	1 mL	77842
Setup Beads: Raw Beads	1 vial	1.8 mL	77844
Capture Beads* (see tables below for more information)	varies	varies	varies*
Human Macrophage/Microglia Panel Detection Antibodies	1 bottle	3.3 mL	varies*
Human Macrophage/Microglia Panel Standard Cocktail, Lyophilized	1 vial	lyophilized	varies*
LEGENDplex <sup>™</sup> SA-PE	1 bottle	3.3 mL	77743
LEGENDplex <sup>™</sup> Matrix B6, Lyophilized	1 vial	lyophilized	750000824
LEGENDplex <sup>™</sup> Assay Buffer	1 bottle	25 mL	77562
LEGENDplex <sup>™</sup> Wash Buffer, 20X	1 bottle	25 mL	77564
Filter Plate**or V-bottom Plate***	1 plate		76187** or 76883***
Plate Sealers	4 sheets		78101

\* For full panel, premixed beads are provided ready-to-use. For subpanels, individual beads are provided at 13X concentration. For Standard and Detection Antibodies, full panels use part numbers and subpanels use catalog numbers (See tables below for details).

\*\* For kit with filter plate. \*\*\* For kit with V-bottom plate. Only one plate is provided for each kit.

#### For Macrophage/Microglia Panel (Full Panel):

Kit Components	Quantity	Volume	Part #
Human Macrophage/Microglia Panel Premixed Beads	1 bottle	3.3 mL	75064
Human Macrophage/Microglia Panel Detection Antibodies	1 bottle	3.3 mL	75058
Human Macrophage/Microglia Panel Standard Cock- tail, Lyophilized	1 vial	lyophi- lized	75060

#### For Macrophage/Microglia Subpanels:

Kit Components	Quantity	Volume	Cat.#
LEGENDplex <sup>™</sup> Human IL-12p70 Capture Bead A4, 13X	1 vial	270 μL	740512
LEGENDplex <sup>™</sup> Human TNF-α Capture Bead A5, 13X	1 vial	270 μL	740513
LEGENDplex <sup>™</sup> Human IL-6 Capture Bead A6, 13X	1 vial	270 μL	740514
LEGENDplex <sup>™</sup> Human IL-4 Capture Bead A7, 13X	1 vial	270 μL	740515
LEGENDplex™ Human IL-10 Capture Bead A8, 13X	1 vial	270 μL	740516
LEGENDplex™ Human IL-1β Capture Bead A10, 13X	1 vial	270 μL	740517
LEGENDplex <sup>™</sup> Human Arginase Capture Bead B2, 13X	1 vial	270 μL	740518
LEGENDplex™ Human TARC Capture Bead B3, 13X	1 vial	270 μL	740519
LEGENDplex <sup>™</sup> Human IL-1RA Capture Bead B4, 13X	1 vial	270 μL	740520
LEGENDplex <sup>™</sup> Human IL-12p40 Capture Bead B5, 13X	1 vial	270 μL	740521
LEGENDplex™ Human IL-23 Capture Bead B6, 13X	1 vial	270 μL	740522
LEGENDplex™ Human IFN-γ Capture Bead B7, 13X	1 vial	270 μL	740523
LEGENDplex™ Human IP-10 Capture Bead B9, 13X	1 vial	270 μL	740524
LEGENDplex™ Human Macrophage/Microglia Panel Detection Antibodies	1 bottle	3.3 mL	740510
LEGENDplex™ Human Macrophage/Microglia Panel Standard	1 vial	lyophi- lized	740511

Please refer to **Beads ID and Panel-Specific Target Selection table (Table 1, page 5),** to see which capture beads are included in each panel

#### Materials to be Provided by the End-User

• A flow cytometer equipped with two lasers (e.g., a 488 nm blue laser or 532 nm green laser and a 633-635 nm red laser) capable of distinguishing 575 nm and 660 nm or a flow cytometer equipped with one laser (e.g., 488 nm blue laser) capable of distinguishing 575 nm and 670 nm.

Flow Cytometer	Reporter Channel	Channel Emission	Classification Channel	Channel Emission	Compensa- tion needed?
BD Accuri <sup>™</sup> C6™	FL2	585 nm	FL4	675 nm	No*
BD FACSCanto, BD FACSCanto™II	PE	575 nm	APC	660 nm	No*
BD <sup>™</sup> LSR, LSR II BD LSRFortessa™	PE	575 nm	APC	660 nm	No*
Gallios™	PE	575 nm	APC	660 nm	No*
CytoFLEX	PE	585 nm	APC	660 nm	No*
NovoCyte	PE	572 nm	APC	660 nm	No*
Attune <sup>™</sup> NxT	PE	574 nm	APC	670 nm	No*

#### Partial list of compatible flow cytometers:

\*Compensation is not required for the specified flow cytometers when set up properly.

For setting up various flow cytometers, please visit: **www.biolegend.com/ legendplex** and click on the **Instrument Setup** tab.

- Multichannel pipettes capable of dispensing 5  $\mu L$  to 200  $\mu L$
- Reagent reservoirs for multichannel pipette
- Polypropylene microfuge tubes (1.5 mL)
- Laboratory vortex mixer
- Sonicator bath (e.g., Branson Ultrasonic Cleaner model #B200, or equivalent)
- Aluminum foil
- Absorbent pads or paper towels
- Plate shaker (e.g., Lab-Line Instruments model #4625, or equivalent)
- Tabletop centrifuges (e.g., Eppendorf centrifuge 5415 C, or equivalent)

#### If the assay is performed in a filter plate (recommended);

• A vacuum filtration unit (Millipore MultiScreen <sup>®</sup> HTS Vacuum Manifold, cat # MSVMHTS00 or equivalent). Instructions on how to use the vacuum manifold can be found at the supplier's website.

- A vacuum source (mini vacuum pump or line vacuum, e.g., Millipore Vacuum Pump, catalog # WP6111560, or equivalent)
- If needed, additional Filter plate can be ordered from BioLegend (Cat# 740377 or 740378)

#### If the assay is performed in a V-bottom plate (optional);

- Centrifuge with a swinging bucket adaptor for microtiter plates (e.g., Beckman Coulter Allegra<sup>™</sup> 6R Centrifuge with MICROPLUS CARRIER adaptor for GH3.8 and JS4.3 Rotors).
- If needed, additional V-bottom plate can be ordered from BioLegend (Cat# 740379)

#### **Precautions**

- All blood components and biological materials should be handled as potentially hazardous. Follow universal precautions as established by the Center for Disease Control and Prevention and by the Occupational Safety and Health Administration when handling and disposing of infectious agents.
- Sodium azide has been added to some reagents as a preservative. Although the concentrations are low, sodium azide may react with lead and copper plumbing to form highly explosive metal azides. On disposal, flush with a large volume of water to prevent azide build-up.
- Matrix B6 for LEGENDplex<sup>™</sup> kits contains components of human origin and should be handled as potentially hazardous. The raw material has been screened for infectious diseases and is negative for HIV, HBV and HCV using FDA-approved test methods.
- Do not mix or substitute reagents from different kits or lots. Reagents from different manufacturers should not be used with this kit.
- Do not use this kit beyond its expiration date.
- SA-PE and beads are light-sensitive. Minimize light exposure.

#### Chapter 2: ASSAY PREPARATION

#### Sample Collection and Handling

#### Preparation of Serum Samples:

- Allow the blood to clot for at least 30 minutes and centrifuge for 20 minutes at 1,000 x g.
- Remove serum and assay immediately or aliquot and store samples at <-20°C. Avoid multiple (>2) freeze/thaw cycles.
- When using frozen samples, it is recommended that samples are thawed completely, mixed and centrifuged to remove particulates prior to use.

#### Preparation of Plasma Samples:

- Plasma collection using EDTA as an anti-coagulant is recommended. Centrifuge for 20 minutes at 1,000 x g within 30 minutes of blood collection.
- Remove plasma and assay immediately, or aliquot and store samples at <-20°C. Avoid multiple (>2) freeze/thaw cycles.
- When using frozen samples, it is recommended that samples are thawed completely, mixed well and centrifuged to remove particulates.

#### Preparation of Tissue Culture Supernatant:

• Centrifuge the sample to remove debris and assay immediately. If not possible, aliquot and store samples at ≤-20°C. Avoid multiple (>2) freeze/thaw cycles.

#### **Reagent Preparation**

#### Preparation of Antibody-Immobilized Beads

• If pre-mixed beads are provided in the kit:

Sonicate pre-mixed Beads bottle for 1 minute in a sonicator bath and then vortex for 30 seconds prior to use. If no sonicator bath is available, increase the vortexing time to 1 minute to completely resuspend the beads.

• If individual beads (13X) are provided in the kit:

The individual beads (13X) should be mixed with each other and diluted to 1X final concentration with Assay Buffer prior to use. To mix the beads, follow the steps below (a 5-plex subpanel is used as an example):

- 1. Sonicate the beads vials for 1 minute in a sonicator bath and then vortex for 30 seconds to completely resuspend the beads.
- 2. Calculate the amount of mixed and diluted beads needed for the assay. Prepare extra to compensate for pipetting loss. Each reaction needs  $25 \ \mu$ L of mixed and diluted beads. For 50 reactions, prepare 1.5 mL of mixed beads. For 96 reactions, prepare 3 mL of mixed beads.
- 3. To make 1.5 ml of 5-plex 1X diluted beads, transfer 115  $\mu$ L of each of the 5 individual beads (13X) to a fresh tube (total bead volume = 575  $\mu$ L) and add 925  $\mu$ L of Assay Buffer to make the final volume of 1.5 mL.

#### Preparation of Wash Buffer

- Bring the 20X Wash Buffer to room temperature and mix to bring all salts into solution.
- Dilute 25 mL of 20X Wash Buffer with 475 mL deionized water. Store unused portions between 2°C and 8°C for up to one month.

#### Preparation of Matrix B6 (for Serum or Plasma Samples Only)

 Add 5.0 mL LEGENDplex<sup>™</sup> Assay Buffer to the bottle containing lyophilized Matrix B6. Allow at least 15 minutes for complete reconstitution. Vortex to mix well. Leftover reconstituted Matrix B6 should be stored at ≤-70°C for up to one month.

#### Standard Preparation

- 1. Prior to use, reconstitute the lyophilized Human Macrophage/Microglia Panel Standard Cocktail, with 250  $\mu L$  Assay Buffer.
- 2. Mix and allow the vial to sit at room temperature for 10 minutes, and then transfer the standard to an appropriately labeled polypropylene microfuge tube. This will be used as the top standard C7.

Note: The top standard concentrations of analytes in this panel were set at various concentrations, but may be subject to change from lot to lot (please visit biolegend.com/en-us/legendplex to download a lot-specific certificate of analysis).

- 3. Label 6 polypropylene microfuge tubes as C6, C5, C4, C3, C2 and C1, respectively.
- 4. Add 75  $\mu$ L of Assay Buffer to each of the six tubes. Prepare 1:4 dilution of the top standard by transferring 25  $\mu$ L of the top standard C7 to the C6 tube and mix well. This will be the C6 standard.
- 5. In the same manner, perform serial 1:4 dilutions to obtain C5, C4, C3, C2

and C1 standards (see the table below using the top standard at 10,000 pg/mL as an example). Assay Buffer will be used as the 0 pg/mL standard (C0).

Tube/Standard ID	Serial Dilution	Assay Buffer to add (μL)	Standard to add	Final Conc. (pg/mL)
C7				10,000
C6	1:4	75	25 µL of C7	2,500
C5	1:16	75	25 µL of C6	625
C4	1:64	75	25 µL of C5	156.3
C3	1:256	75	25 µL of C4	39.1
C2	1:1024	75	25 µL of C3	9.8
C1	1:4096	75	25 µL of C2	2.4
C0		75		0

#### **Sample Dilution**

• Serum or plasma samples must be diluted 2-fold with Assay Buffer before being tested (e.g. dilute 50 µL of sample with 50 µL of Assay Buffer).

If further sample dilution is desired, dilution should be done with Matrix B6 to ensure accurate measurement.

Adding serum or plasma samples without dilution will result in low assay accuracy and possibly, clogging of the filter plate.

• For cell culture supernatant samples, the levels of analyte can vary greatly from sample to sample. While the samples can be tested without dilutions, a preliminary experiment may be required to determine the appropriate dilution factor.

If sample dilution is desired, dilution should be done with corresponding fresh cell culture medium or Assay Buffer to ensure accurate measurement.

#### Chapter 3: ASSAY PROCEDURE

The LEGENDplex<sup>™</sup> assay can be performed in a filter plate, or in a V-bottom plate.

- The in-filter plate assay procedure is recommended due to its good sample to sample consistency, assay robustness and ease of handling. This procedure requires a vacuum filtration unit for washing (see Materials to be **Provided by the End-User, page 8)**. If you have performed bead-based multiplex assays before, your lab may already have the vacuum filtration unit set up.
- If the in-filter plate assay procedure is not possible or if you prefer, the assay can be performed in a V-bottom plate.

#### Performing the Assay Using a Filter Plate

- Allow all reagents to warm to room temperature (20-25°C) before use.
- Set the filter plate on an inverted plate cover at all times during assay setup and incubation steps, so that the bottom of the plate does not touch any surface. Touching a surface may cause leakage.
- Keep the plate upright during the entire assay procedure, including the washing steps, to avoid losing beads.
- The plate should be placed in the dark or wrapped with aluminum foil for all incubation steps.
- Standards and samples should be run in duplicate and arranged on the plate in a vertical configuration convenient for data acquisition and analysis (as shown in attached PLATE MAP, page 33). Be sure to load standards in the first two columns. If an automation device is used for reading, the orientation and reading sequence should be carefully planned.
- Pre-wet the plate by adding 100 µL of LEGENDplex<sup>™</sup> 1X Wash Buffer to each well and let it sit for 1 minute at room temperature. To remove the excess volume, place the plate on the vacuum manifold and apply vacuum. Do not exceed 10" Hg of vacuum. Vacuum until wells are drained (5-10 seconds). Blot excess Wash Buffer from the bottom of the plate by pressing the plate on a stack of clean paper towels. Place the plate on top of the inverted plate cover.

For measuring cell culture supernatant samples, load the plate as shown in the table below (in the order from left to right):

	Assay Buffer	Matrix B6	Standard	Sample*
Standard Wells	25 μL		25 μL	
Sample wells	25 μL			25 μL

For measuring serum or plasma samples, load the plate as shown in the table below (in the order from left to right):

	Assay Buffer	Matrix B6	Standard	Sample*
Standard Wells		25 μL	25 μL	
Sample wells	25 μL			25 μL


#### \*See Sample Dilution

- Vortex mixed beads bottle for 30 seconds. Add 25 μL of mixed beads to each well. The volume should be 75 μL in each well after beads addition. (Note: During addition of the beads, shake mixed beads bottle intermittently to avoid bead settling).
- 3. Seal the plate with a plate sealer. **To avoid plate leaking, do not apply positive pressure to the sealer when sealing the plate**. Wrap the entire plate, including the inverted plate cover, with aluminum foil. Place the plate on a plate shaker, secure it and shake at approximate 500 rpm for 2 hours at room temperature.
- 4. Do not invert the plate! Place the plate on the vacuum manifold and apply vacuum as before in Step 1. Add 200 μL of 1X Wash Buffer to each well. Remove Wash Buffer by vacuum filtration. Blot excess Wash Buffer from the bottom of the plate with an absorbent pad or paper towels. Repeat this washing step once more.
- 5. Add 25  $\mu$ L of Detection Antibodies to each well.
- 6. Seal the plate with a fresh plate sealer. Wrap the entire plate, including the inverted plate cover, with aluminum foil. Place the plate on a plate shaker and shake at approximately 500 rpm for 1 hour at room temperature.
- 7. Do not vacuum! Add 25 µL of SA-PE to each well directly.
- 8. Seal the plate with a fresh plate sealer. Wrap the entire plate, including the inverted plate cover, with aluminum foil. Place the plate on a plate shaker and shake at approximate 500 rpm for 30 minutes at room temperature.
- 9. Repeat step 4 above.
- 10. Add 150  $\mu\text{L}$  of 1X Wash Buffer to each well. Resuspend the beads on a plate shaker for 1 minute.
- 11. Read samples on a flow cytometer, preferably within the same day of the assay (Note: Prolonged sample storage can lead to reduced signal).

If the flow cytometer is equipped with an autosampler, read the plate directly using the autosampler. **Please be sure to program the autosampler** 

## to resuspend beads in the well immediately before taking samples. The probe height may need to be adjusted when using an autosampler.

If an autosampler is not available, the samples can be transferred from the filter plate to micro FACS (or FACS) tubes and read manually.



#### LEGENDplex<sup>™</sup> Human Macrophage/Microglia Panel <u>Performing the Assay Using a V-bottom Plate</u>

- Allow all reagents to warm to room temperature (20-25°C) before use.
- Keep the plate upright during the entire assay procedure, including the washing steps, to avoid losing beads.
- The plate should be placed in the dark or wrapped with aluminum foil for all incubation steps.
- Standards and samples should be run in duplicate and arranged on the plate in a vertical configuration convenient for data acquisition and analysis (as shown in attached PLATE MAP, page 33). Be sure to load standards in the first two columns. If an automation device is used for reading, the orientation and reading sequence should be carefully planned.
- 1. For measuring cell culture supernatant samples, load the plate as shown in the table below (in the order from left to right):

	Assay Buffer	Matrix B6	Standard	Sample*
Standard Wells	25 μL		25 μL	
Sample wells	25 μL			25 μL

For measuring serum or plasma samples, load the plate as shown in the table below (in the order from left to right):

	Assay Buffer	Matrix B6	Standard	Sample*
Standard Wells		25 μL	25 μL	
Sample wells	25 μL			25 μL

\*See Sample Dilution

- Vortex mixed beads for 30 seconds. Add 25 μL of mixed beads to each well. The total volume should be 75 μL in each well after beads addition. (Note: During beads addition, shake mixed beads bottle intermittently to avoid bead settling).
- 3. Seal the plate with a plate sealer. Cover the entire plate with aluminum foil to protect the plate from light. Shake at 800 rpm on a plate shaker for 2 hours at room temperature (Depending on the shaker, the speed may need to be adjusted. The optimal speed is one that is high enough to keep beads in suspension during incubation, but not too high so it causes spill from the wells).
- 4. Centrifuge the plate at 1050 rpm (~250 g) for 5 minutes, using a swinging bucket rotor (G.H 3.8) with microplate adaptor (Please refer to Materials to be Provided by the End-User, page 8). Do not use excessive centrifugation speed as it may make it harder to resuspend beads in later steps. Make

### sure the timer of the centrifuge works properly and standby to make sure the centrifuge reaches preset speed.

5. Immediately after centrifugation, dump the supernatant into a sink by quickly inverting and flicking the plate in one continuous and forceful motion. Do not worry about losing beads even if the pellet is not visible. The beads will stay in the tip of the well nicely. Blot the plate on a stack of clean paper towel and drain the remaining liquid from the well as much as possible. Be careful not to disturb the bead pellet.


Alternatively, removal of the supernatant may be completed using a multichannel pipette set at 75  $\mu$ L. Try to remove as much liquid as possible without removing any beads. Be sure to change pipette tips between each row or column.

- Wash the plate by dispensing 200 μL of 1X Wash Buffer into each well and incubate for one minute. Repeat step 4 and 5 above. A second wash is optional, but may help reduce background.
- 7. Add 25  $\mu$ L of Detection Antibodies to each well.
- 8. Seal the plate with a new plate sealer. Cover the entire plate with aluminum foil to protect the plate from light. Shake at 800 rpm on a plate shaker for 1 hour at room temperature.
- 9. Do not wash the plate! Add 25 µL of SA-PE to each well directly.
- Seal the plate with a new plate sealer. Wrap the entire plate with aluminum foil and shake the plate on a plate shaker at approximate 800 rpm for 30 minutes at room temperature.
- 11. Repeat step 4 and 5.
- 12. Wash the plate by dispensing 200  $\mu$ L of 1X Wash Buffer into each well and incubate for one minute. Repeat step 4 and 5 above. This washing step is optional but it helps to reduce the background.
- 13. Add 150  $\mu\text{L}$  of 1X Wash Buffer to each well. Resuspend the beads by pipetting.
- 14. Read samples on a flow cytometer, preferably within the same day of the assay (Note: Prolonged sample storage can lead to reduced signal).

If the flow cytometer is equipped with an autosampler, the samples can be read directly. Please be sure to program the autosampler to resuspend beads in the well immediately before taking samples. The probe height may need to be adjusted when using an autosampler.

If an autosampler is not available, the samples can be transferred from the plate to micro FACS (or FACS) tubes and read manually.

#### Assay Procedure Summary for V-bottom Plate



#### Chapter 4: FLOW CYTOMETER SETUP

In order to generate reliable data, the flow cytometer must be set up properly before data acquisition.

The setup instructions have been removed from this manual and uploaded onto our website to save paper.

To access the setup instructions, please visit: **www.biolegend.com/legendplex** and click on the **Instrument Setup** tab.

#### Chapter 5: DATA ACQUISITION AND ANALYSIS

#### Data Acquisition

- 1. Before reading samples, make sure that the flow cytometer is set up properly.
- 2. Create a new template or open an existing template (for details on how to create a cytometer-specific template, please refer to the Flow Cytometer Setup Guide).
- 3. Vortex each sample for 5 seconds before analysis.
- 4. Set the flow rate to low. Set the number of beads to be acquired to about 300 per analyte (e.g., acquire 2,400 beads for a 8-plex assay or 4000 beads for a 13-plex assay). Do not set to acquire total events as samples may contain large amounts of debris. Instead, create a large gate to include both Beads A and Beads B (gate A+B) and set to acquire the number of events in gate A + B. This will exlude majority of the debris.

Note: Do not acquire too few or too many beads. Too few beads acquired may result in high CVs and too many beads acquired may result in slow data analysis later.

5. Read samples.

When reading samples, set the flow cytometer to setup mode first and wait until bead population is stabilized before recording or switching to acquisition mode.

To simplify data analysis using the LEGENDplex<sup>™</sup> Data Analysis Software, read samples in the same order as shown on the PLATE MAP attached at the end of the manual. For an in-plate assay, read column by column (A1, B1, C1...A2, B2, C2...).

When naming data files, try to use simple names with a consecutive numbering for easy data analysis (e.g. for standards, C0.001, C0.002, C1.003, C1.004, C2.005, C2.006, C3.007, C3.008, ... C7.015, C7.016; for samples, S1.017, S1.018, S2.019, S2.020, S3.021, S3.022...)

Store all FCS files in the same folder for each assay. If running multiple assays, create a separate folder for each assay.

6. Proceed to data analysis using LEGENDplex<sup>™</sup> Data Analysis Software when data acquisition is completed.


#### **Data Analysis**

The assay FCS files should be analyzed using BioLegend's LEGENDplex<sup>™</sup> data analysis software. The program is offered free of charge with the purchase of any LEGENDplex<sup>™</sup> assay. For further information regarding access to, and use of the program please visit **biolegend.com/en-us/legendplex**.

#### Chapter 6: ASSAY CHARACTERIZATION

#### **Representative Standard Curve**

This standard curve was generated using the LEGENDplex<sup>™</sup> Human Macrophage/Microglia Panel for demonstration purposes only. A standard curve must be run with each assay.



#### Assay Sensitivity

The assay sensitivity is the theoretical limit of detection calculated using the LEGENDplex<sup>™</sup> Data Analysis Software by applying a 5-paramater curve fitting algorithm. Assay Sensitivity presented here is ≤Mean LOD + 2xST-DEV LOD.

Analyte	LOD in Assay Buffer (pg/mL)	LOD in Matrix (pg/mL)
Human IL-12(p70)	1.20	2.40
Human TNF-α	2.10	2.30
Human IL-6	1.70	1.80
Human IL-4	2.10	2.90
Human IL-10	1.47	1.50
Human IL-1β	2.70	5.60
Human Arginase	256.5	322.2
Human TARC	2.90	5.70
Human IL-1RA	107.00	103.20

Human IL-12(p40)	11.80	21.90
Human IL-23	4.40	11.32
Human IFN-γ	2.90	5.20
Human IP-10	3.60	4.80

#### Cross-Reactivity

The following human recombinant proteins were tested at 50 ng/mL using the LEGENDplex<sup>™</sup> Human Macrophage/Microglia Panel. No or negligible cross-reactivity was found for all the tested analytes.

Arginase	CXCL12	Eotaxin	EPO	GM-CSF	IFN-γ	IGF-II
IL-10	IL-12(p40)	IL-12(p70)	IL-13	IL-17A	IL-1RA	IL-1α
IL-1β	IL-2	IL-22	IL-23	IL-33	IL-4	IL-6
IL-8	IP-10	ITAC	MCP-1	MCP-4	MIP-1a	MIP-1δ
MIP-3a	MIP-3β	MPIF-1	NGAL	Paxillin	TARC	TGF-α
TGF-β1	TGF-β2	TGF-β3	TNF-α	TNF-β		

#### Accuracy (Spike Recovery)

For spike recovery in serum, target proteins with known concentrations were spiked into human serum at three different levels within the assay range. The spiked samples were then assayed, and the measured concentrations were compared with the expected values.

Analyte	% of Rcovery in Serum	Analyte	% of Rcovery in Serum
Human IL-12(p70)	81%	Human TARC	86%
Human TNF-α	82%	Human IL-1RA	98%
Human IL-6	88%	Human IL-12(p40)	93%
Human IL-4	73%	Human IL-23	84%
Human IL-10	84%	Human IFN-γ	109%
Human IL-1β	70%	Human IP-10	97%
Human Arginase	63%		

#### Linearity of Dilution

For testing linearity of dilution, serum samples were first diluted two-fold with Assay Buffer, then serially diluted 1:2, 1:4, 1:8 with Matrix B6 and assayed. The measured concentrations of serially diluted samples were then compared with that of the two-fold diluted samples.

Analyte	Linearity of Dilution	Analyte	Linearity of Dilution
Human IL-12(p70)	116%	Human TARC	101%
Human TNF-α	123%	Human IL-1RA	122%
Human IL-6	113%	Human IL-12(p40)	111%
Human IL-4	116%	Human IL-23	108%
Human IL-10	113%	Human IFN-γ	100%
Human IL-1β	116%	Human IP-10	106%
Human Arginase	114%		

#### **Intra-Assay Precision**

Two samples with different concentrations of target proteins were analyzed in one assay with 16 replicates for each sample. The intra-assay precision was calculated as below.

Analyte	Sample	Mean (pg/mL)	STDEV	%CV
11/1/m20	Sample 1	57.0	5.2	9%
Human IL-12(p70)	Sample 2	230	25.6	11%
	Sample 1	55.1	7.1	13%
Human TNF-α	Sample 2	194.5	20.7	11%
	Sample 1	47.3	6.6	14%
Human IL-6	Sample 2	186.1	23.9	13%
	Sample 1	45.8	5.2	11%
Human IL-4	Sample 2	176.6	7.8	4%
	Sample 1	49.5	5.4	11%
Human IL-10	Sample 2	198.3	18.9	10%

	Sample 1	59.1	9.0	15%
Human IL-1β	Sample 1	59.1	9.0	15%
· · • · · • · · ·  •	Sample 2	243.1	23.1	9%
Human Arginase	Sample 1	3043.1	478.4	16%
Human Arginase	Sample 2	9958.0	1498.2	15%
Human TARC	Sample 1	63.4	7.5	12%
Human IARC	Sample 2	211.7	19.7	9%
	Sample 1	2462.0	376.7	15%
Human IL-1RA	Sample 2	10399.2	1513.2	15%
Human II 12n40	Sample 1	235.6	35.9	15%
Human IL-12p40	Sample 2	903.1	57.3	6%
Human IL-23	Sample 1	25.6	3.2	13%
Human IL-23	Sample 2	96.8	6.3	7%
	Sample 1	11.2	4.0	35%
Human IFN-γ	Sample 2	79.9	7.9	10%
	Sample 1	63.7	7.9	12%
Human IP-10	Sample 2	253.1	10.9	4%

#### Inter-Assay Precision

Two samples with different concentrations of target proteins were analyzed in three independent assays with 3 replicates for each sample. The interassay precision was calculated as below.

Analyte	Sample	Mean (pg/mL)	STDEV	%CV
Liuman II (12/n70)	Sample 1	46.5	3.7	8%
Human IL-12(p70)	Sample 2	161.5	10.4	6%
	Sample 1	50.0	1.5	3%
Human TNF-α	Sample 2	176.0	5.5	3%
	Sample 1	48.1	7.7	16%
Human IL-6	Sample 2	152.7	2.5	2%
	Sample 1	52.1	6.8	13%
Human IL-4	Sample 2	167.2	7.9	5%
	Sample 1	48.4	1.3	3%
Human IL-10	Sample 2	160.4	15.6	10%

Human IL-1β	Sample 1	46.5	1.9	4%
numan ic-1p	Sample 2	168.8	11.9	7%
	Sample 1	2346.1	350.4	15%
Human Arginase	Sample 2	7390.5	457.0	6%
	Sample 1	54.9	5.0	9%
Human TARC	Sample 2	191.2	11.1	6%
Human IL-1RA	Sample 1	2026.2	275.5	14%
Human IL-IKA	Sample 2	7661.7	158.3	2%
12(nAQ)	Sample 1	194.5	19.2	10%
Human IL-12(p40)	Sample 2	748.7	18.0	2%
	Sample 1	27.7	4.9	18%
Human IL-23	Sample 2	89.0	9.4	11%
	Sample 1	59.8	3.8	6%
Human IFN-γ	Sample 2	146.2	16.0	11%
Lluman ID 10	Sample 1	72.0	26.1	36%
Human IP-10	Sample 2	279.3	75.3	27%

LEGENDplex<sup>™</sup> Human Macrophage/Microglia Panel

#### **Biological Samples**

#### Serum and Plasma (Samples are not paired)

Normal human serum samples (n=20) were tested for endogenous levels of the Macrophage/Microglia related cytokines. The concentrations measured are shown below.

Analyte	Range (pg/mL)	% of Detectable	Median (pg/mL)
Human IL-12(p70)	ND - 26.5	25%	10.4
Human TNF-α	ND - 98.6	70%	1.4
Human IL-6	ND - 44.1	95%	2.2
Human IL-4	ND - 37.4	55%	1.1
Human IL-10	ND - 33.1	90%	0.9
Human IL-1β	ND - 122.6	30%	19.7

Human Arginase	250.8 - 31754.1	100%	2870.5
Human TARC	11.2 - 529.3	100%	110.7
Human IL-1RA	ND - 624.9	60%	164.6
Human IL-12(p40)	ND - 817.2	85%	23.2
Human IL-23	ND - 59.6	70%	1.4
Human IFN-γ	ND - 202.4	35%	12.2
Human IP-10	23.8 - 320.3	100%	48.8

ND = Non-detectable

Normal human plasma samples (n=20) were tested for endogenous levels of the Macrophage/Microglia related cytokines. The concentrations measured are shown below.

Analyte	Range (pg/mL)	% of Detectable	Median (pg/mL)
Human IL-12(p70)	ND - 22.6	45%	8.8
Human TNF-α	ND - 79.0	95%	2.9
Human IL-6	ND - 44.2	90%	3.6
Human IL-4	0.9 - 53.5	100%	9.7
Human IL-10	1.0 - 31.5	100%	2.4
Human IL-1β	ND - 29.1	90%	29.1
Human Arginase	ND - 6316.1	95%	2278.5
Human TARC	4.3 - 106.1	100%	32.1
Human IL-1RA	ND - 323.7	45%	115.4
Human IL-12(p40)	6.1 - 298.7	100%	83.9
Human IL-23	ND - 14.7	70%	6.0
Human IFN-γ	ND - 85.1	40%	25.2
Human IP-10	8.9 - 164.7	100%	43.9

ND = Non-detectable

#### **Cell Culture Supernatant**

Human monocytes (1 x 10<sup>6</sup> cells/mL) were differentiated using GM-CSF (25 ng/mL) for 5 days. The differentiated macrophages were further polarized using various stimulation agents (100 ng/mL LPS and 25 ng/mL IFN- $\gamma$ ; 20 ng/mL IL-4). Supernatants were collected after 48 hours of culturing and assayed with LEGENDplex<sup>TM</sup> Human Macrophage/Microglia Panel. The results (all in pg/mL) are summarized below.

Analyte	Control	LPS + IFN-γ	IL-4
Human IL-12(p70)	0.9	210.0	0.9
Human TNF-α	1.1	21193.4	1.2
Human IL-6	38.2	27551.5	88.0
Human IL-4	1.5	13.0	21269.6*
Human IL-10	5.4	253.8	8.9
Human IL-1β	1.1	457.4	1.4
Human Arginase	4161.0	4231.2	5697.1
Human TARC	26.3	26.6	181.0
Human IL-1RA	51581.5	37372.6	59116.2
Human IL-12(p40)	6.6	81748.7	224.8
Human IL-23	1.7	861.1	33.4
Human IFN-γ	4.3	2035.9**	33.0
Human IP-10	14.6	9556.0	35.1

\*High signal results from IL-4 added as a stimulant. \*\* High signal results from IFN- $\gamma$  added as a stimulant.

The cell culture was rested in fresh culture media. The polarized cells were re-stimulated with the same conditions for 48 hours and supernatants were collected and assayed with LEGENDplex<sup>™</sup> Human Macrophage/Microglia Panel. The results (all in pg/mL) are summarized below.

Analyte	Control	LPS + IFN-γ	IL-4
Human IL-12(p70)	0.9	14.8	0.9
Human TNF-α	0.8	1516.6	3.5
Human IL-6	30.9	21831.5	51.3
Human IL-4	16.1	6.7	39542.5*
Human IL-10	13.3	34.4	14.8
Human IL-1β	0.7	20.8	0.9
Human Arginase	3336.0	4417.1	6468.7
Human TARC	5.6	14.2	762.2
Human IL-1RA	10207.3	10528.4	33955.8
Human IL-12(p40)	7.7	3908.3	349.1
Human IL-23	1.7	70.4	35.0
Human IFN-γ	4.3	2906.5**	42.4
Human IP-10	5.6	9382.3	31.5

\*High signal results from IL-4 added as a stimulant. \*\* High signal results from IFN-γ added as a stimulant.

#### TROUBLESHOOTING

Problem	Possible Cause	Solution
Bead popula- tion shifting upward or downward dur- ing acquisition	The strong PE signal from high concentra- tion samples or stan- dards may spill over to classification Channel (e.g., FL3/FL4/APC) and mess up the bead separation.	Optimize instrument settings using Kit Setup Beads, and make appropriate com- pensation between channels.
	Vacuum pressure is insufficient or vacuum manifold does not seal properly.	Increase vacuum pressure such that 0.2 mL buffer can be suctioned in 3-5 seconds. Clean the vacuum manifold and make sure no debris on the manifold. Press down the plate on the manifold to make a good seal.
		Centrifuge samples just prior to assay setup and use supernatant. If high lipid content is present, remove lipid layer after centrifugation. Sample may need dilution if too viscous.
Filter plate will		If some wells are still clogged during wash- ing, try the following:
not vacuum or some wells clogged	Samples have insoluble particles or sample is too viscous (e.g., serum	1). Add buffer to all the wells, pipette up and down the clogged wells and vacuum again.
	and plasma samples)	2). Use a piece of clean wipe, wipe the un- der side of the clogged wells and vacuum again.
		3). Take a thin needle (e.g., insulin needle), while holding the plate upward, poke the little hole under each of the clogged wells and vacuum again. Do not poke too hard or too deep as it may damage the filter and cause leaking.
	Filter plate was used without pre-wet.	Pre-wet plate with wash buffer before run- ning the assay.

	Beads inappropriately prepared	Sonicate bead vials and vortex just prior to addition. Agitate mixed beads intermit- tently in reservoir while pipetting this into the plate.
Insufficient bead count or	Samples cause beads aggregation due to particulate matter or viscosity.	Centrifuge samples just prior to assay setup and use supernatant. If high lipid content is present, remove lipid layer after centrifugation. Sample may need dilution if too viscous.
slow reading	Beads were lost during washing for in-tube assay	Make sure beads are spun down by visu- ally check the pellet (beads are in light blue or blue color). Be very careful when removing supernatant during washing.
	Probe might be par- tially clogged.	Sample probe may need to be cleaned, or if needed, probe should be removed and sonicated.
	Vacuum pressure set too high	Adjust vacuum pressure such that 0.2 mL buffer can be suctioned in 3-5 seconds. Do not exceed 10" Hg of vacuum.
Plate leaked	Plate set directly on table or absorbent tow- els during incubations or reagent additions	Set plate on plate holder or raised edge so bottom of filter is not touching any surface.
	Liquid present on the under side of the plate after vacuum	After washing, press down plate firmly on a stack of clean paper towels to dry the underside of the plate.
	Pipette touching and damaged plate filter during additions.	Pipette to the side of wells.
High Back-	Background wells were contaminated	Avoid cross-well contamination by chang- ing tips between pipetting when perform- ing the assay using a multichannel pipette.
ground	Insufficient washes	The background may be due to non- specific binding of SA-PE. Increase number of washes.
Debris (FSC/ SSC) during sample acquisi- tion	Debris or platelet may exist in sample solu- tion.	Centrifuge samples before analyzing samples. Remove platelet as much as possible.
0		

r	1	
	Beads aggregation	Sonicate and vortex the Beads prior to use.
Variation be-	Multichannel pipette may not be calibrated or inconsistent pipet- ting	Calibrate Pipette. Ensure good pipetting practice. Prime pipette before use may help.
tween duplicate samples	Plate washing was not uniform	Make sure all reagents are vacuumed out completely in all wash steps.
	Samples may contain particulate matters.	Centrifuge samples just prior to assay setup and use supernatant. If high lipid content is present, remove lipid layer after centrifugation. Sample may need dilution if too viscous.
Low or poor standard curve	The standard was in- correctly reconstituted, stored or diluted	Follow the protocol to reconstitute, store and dilute standard. Double check your calculation.
signal	Wrong or short incuba- tion time	Ensure the time of all incubations was appropriate.
Signals too high, standard curves satu-	PMT value for FL2/PE set too high	Make sure the PMT setting for the re- porter channel is appropriate
rated	Plate incubation time was too long	Use shorter incubation time.
	Samples contain no or below detectable levels of analyte	Make sure the experiment to generate the samples worked. Use proper positive controls.
Sample read- ings are out of range	Samples concentrations higher than highest standard point.	Dilute samples and analyze again.
	Standard curve was saturated at higher end of curve.	Make sure the PMT setting for the re- porter channel is appropriate. Use shorter incubation time if incubation time was too long
Missed beads populations during reading, or distribution	Sample may cause some beads to ag- gregate.	Centrifuge samples just prior to assay setup and use supernatant. If high lipid content is present, remove lipid layer after centrifugation. Sample may need dilution if too viscous.
is unequal	Beads populations are not mixed properly	Make sure all bead populations are mixed. and in similar numbers.

# PLATE MAP (for in-plate assay)

	1	2	æ	4	5	9	7	8	6	10	11	12
A	CO	C4	Sample1	Sample5	Sample 9	Sample 13	Sample 17	Sample 21	Sample 25	Sample 29	Sample 33	Sample 37
Β	CO	C4	Sample1	Sample5	Sample 9	Sample 13	Sample 17	Sample 21	Sample 25	Sample 29	Sample 33	Sample 37
U	C1	CS	Sample2	Sample6	Sample 10	Sample 14	Sample 18	Sample 22	Sample 26	Sample 30	Sample 34	Sample 38
D	C1	CS	Sample2	Sample6	Sample 10	Sample 14	Sample 18	Sample 22	Sample 26	Sample 30	Sample 34	Sample 38
ш	C2	CG	Sample3	Sample7	Sample 11	Sample 15	Sample 19	Sample 23	Sample 27	Sample 31	Sample 35	Sample 39
ш	C2	CG	Sample3	Sample7	Sample 11	Sample 15	Sample 19	Sample 23	Sample 27	Sample 31	Sample 35	Sample 39
U	C3	C7	Sample4	Sample8	Sample 12	Sample 16	Sample 20	Sample 24	Sample 28	Sample 32	Sample 36	Sample 40
Т	ß	C	Sample4	Sample4 Sample8	Sample 12	Sample 16	Sample 20	Sample 24	Sample 28	Sample 32	Sample 36	Sample 40

BioLegend®

LEGENDplex<sup>™</sup> Kits are manufactured by **BioLegend** 8999 BioLegend Way San Diego, CA 92121 Tel: 1.858.768.5800 Tel: US & Canada Toll-Free: 1.877.Bio-Legend (1.877.246.5343) Fax: 1.877.455.9587 Email: info@biolegend.com biolegend.com

For a complete list of world-wide BioLegend offices and distributors, please visit our website at: biolegend.com

740502/740503F\_R05