

Please read the entire manual before running the assay.

BioLegend.com

It is highly recommended that this manual be read in its entirety before using this product. Do not use this kit beyond the expiration date.

For Research Purposes Only. Not for use in diagnostic or therapeutic procedures. Purchase does not include or carry the right to resell or transfer this product either as a stand-alone product or as a component of another product. Any use of this product other than the permitted use without the express written authorization of BioLegend is strictly prohibited.

Table of ContentsPage	ge
Chapter 1: KIT DESCRIPTION	3
Introduction	3
Principle of the Assay	3
Beads Usage	4
Storage Information	6
Materials Supplied	6
Materials to be Provided by the End-User	8
Precautions	9
Chapter 2: ASSAY PREPARATION	10
Sample Collection and Handling	10
Reagent Preparation	10
Standard Preparation	11
Sample Dilution	12
Chapter 3: ASSAY PROCEDURE	13
Performing the Assay Using a Filter Plate	13
Performing the Assay Using a V-bottom Plate	16
Chapter 4: FLOW CYTOMETER SETUP	19
Chapter 5: DATA ACQUISITION AND ANALYSIS	· 19
Data Acquisition	19
Data Analysis	20
Chapter 6: ASSAY CHARACTERIZATION	• 21
Standard Curve	21
Assay Sensitivity	21
Cross-Reactivity	22
Accuracy	22
Linearity of Dilution	23

Human A	Anti-Virus	Response	Panel 1	Mix and	Match	Subpanel

Intra-Assay Precision	24
Inter-Assay Precision	25
Biological Samples	26
TROUBLESHOOTING	29
PLATE MAP	33

Chapter 1: KIT DESCRIPTION

Introduction

In response to pathogens, especially viruses, cells release interferons and other cytokines to fight the infections. Interferons are typically divided into three types: 1 (e.g., INF- α , IFN- β), 2 (e.g., IFN- γ), and 3 (e.g., IFN- λ 1, IFN- λ 2). All interferons are important for fighting viral infections and for regulating the immune system. In addition, interferons are critically involved in cancer and autoimmune diseases such as psoriasis, systemic lupus erythematosus, and multiple sclerosis. Studying the expression profile of interferons and other related cytokines is pivotal to understand the immune responses against pathogens and related disease processes.

The LEGENDplexTM Human Anti-Virus Response Panel 1 is a bead-based multiplex assay, utilizing fluorescence–encoded beads suitable for use on various flow cytometers. This panel allows simultaneous quantification of 13 human proteins, including interferons (α , β , γ , $\lambda 1$ and $\lambda 2$), interleukins (1 β , 6, 8, 10, 12), TNF- α , IP-10 and GM-CSF. The Type 1/2/3 Interferon Panel is a subpanel of the 13-plex Anti-Virus Response Panel 1, which allows for simultaneous quantification of the five Interferons. Both panels provide high sensitivities and broad dynamic range. The two panels have been validated for use on serum and cell culture supernatant samples. Use plasma samples with caution due to sample viscosity and existence of particulates in such samples.

The Anti-Virus Response Panel 1 is designed to allow flexible customization within the panel. Please visit **www.biolegend.com/legendplex** for more information on how to mix and match within the panel.

This assay is for research use only.

Principle of the Assay

BioLegend's LEGENDplex[™] assays are bead-based immunoassays using the same basic principle as sandwich immunoassays.

Beads are differentiated by size and internal fluorescence intensities. Each bead set is conjugated with a specific antibody on its surface and serves as the capture beads for that particular analyte. When a selected panel of capture beads is mixed and incubated with a sample containing target analytes specific to the capture antibodies, each analyte will bind to its specific capture beads. After washing, a biotinylated detection antibody cocktail is added, and each detection antibody in the cocktail will bind to its specific analyte bound on the capture beads, thus forming capture bead-analyte-detection antibody sandwiches. Streptavidin-phycoerythrin (SA-PE) is subsequently added, which will bind to the biotinylated detection antibodies, providing fluorescent signal intensities in proportion to the amount of bound analytes.


Since the beads are differentiated by size and internal fluorescence intensity on a flow cytometer, analyte-specific populations can be segregated and quantified by the PE fluorescent signal. The concentration of a particular analyte is determined by a standard curve generated in the same assay.

Beads Usage

The Anti-Virus Response Panel 1 uses two sets of beads. Each set has a unique size that can be identified based on their forward scatter (FSC) and side scatter (SSC) profiles (Beads A and Beads B, Figure 1). Each bead set can be further resolved based on their internal fluorescence intensities. The internal dye can be detected using FL3, FL4, or APC channel, depending on the type of flow cytometer used. The smaller Beads A consists of 6 bead populations and the larger Beads B consists of 7 bead populations (Figure 2-3).

Using a total of 13 bead populations out of 14 distinguished by size and internal fluorescent dye, the Anti-Virus Response Panel 1 allows simultaneous detection of 13 proteins in a single sample. Each analyte is associated with a particular bead set as indicated (Figures 2-3 and Table 1).


Figure 1. Beads Differentiated by Size



Beads A = smaller beads


Beads B = larger beads





Tel: 858-768-5800

Figure 3. Beads B Classification by FL4



For Beads usage in various panels, please refer to Table 1 below:

Table 1 Beads ID	Panel Specific	Target Selection and	Target information
Table 1. Deaus ID,	, ranei specific	larget Selection and	i laiget intormation

Target	Bead ID	Full Panel Cat# 741269* & 741270**	Sunpanel Cat# 741271* & 741272**	Top Standard Concentrations (ng/mL)
IFN-λ1 (IL-29)	A3	V	V	
L-1β	A4	V		Note: The top standard concen-
IL-6	A5	V		trations of analytes
TNF-α	A6	V		in this panel were set at various
IP-10	A7	V		concentrations, but
IL-8	A10	V		may be subject to change from lot
IL-12p70	B2	v		to lot (please visit
IFN-α2	B3	v	V	biolegend.com/
IFN-λ2 (IL-28A)	B4	V	V	en-us/legendplex to download a lot- specific certificate
GM-CSF	B5	v		of analysis).
IFN-β	B6	V	V	
IL-10	B7	V		
IFN-γ	В9	V	V	

* Cat# for kit with Filter plate. **Cat# for kit with V-bottom Plate

Bead ID is used to associate a bead population to a particular analyte when using the LEGENDplex[™] data analysis software program. For further information regarding the use of the program please visit biolegend.com/en-us/legendplex.

Storage Information

Recommended storage for all original kit components is between 2°C and 8°C. DO NOT FREEZE Beads, Detection Antibodies or SA-PE.

- Once the standards have been reconstituted, immediately transfer contents into polypropylene vials. DO NOT STORE RECONSTITUTED STANDARDS IN GLASS VIALS.
- Upon reconstitution, leftover standard and Matrix A should be stored at ≤-70°C for use within one month. Avoid multiple (>2) freeze-thaw cycles. Discard any leftover diluted standards.

Materials Supplied

The LEGENDplex[™] kit contains reagents for 100 tests, listed in the table below. When assayed in duplicate, this is enough for an 8-point standard curve and 40 samples.

For the Mix and Match Subpanels, individual beads are provided at 13X concentration. The Buffer Set contains Setup Beads, all Buffers, Plate Sealers, Matrix, and SA-PE.

Kit Components	Quantity	Volume	Cat #
Capture Beads* (see tables below for more information)	varies	270 μL	varies
LEGENDplex [™] Human Anti-Virus Re- sponse Panel 1 Detection Antibodies	1 bottle	3.3 mL	741273
LEGENDplex™ Human Anti-Virus Response Panel 1 Standard	1 vial	lyophilized	741274
LEGENDplex™ Buffer Set I	1		740623
Filter Plate* or V-bottom Plate**	1 Plate		740377*or 740379**

* For kit with filter plate. ** For kit with V-bottom plate.

Bead Name	Quantity	Volume	Cat#
LEGENDplex™ Human IFN-λ1 Capture Bead A3, 13X	1 vial	270 μL	741275
LEGENDplex [™] Human IL-1β Capture Bead A4, 13X	1 vial	270 μL	741344
LEGENDplex™ Human IL-6 Capture Bead A5, 13X	1 vial	270 μL	740356
LEGENDplex™ Human TNF-α Capture Bead A6, 13X	1 vial	270 μL	740359
LEGENDplex™ Human IP-10 Capture Bead A7, 13X	1 vial	270 μL	740363
LEGENDplex [™] Human IL-8 Capture Bead A10, 13X	1 vial	270 μL	741276
LEGENDplex [™] Human IL-12p70 Capture Bead B2, 13X	1 vial	270 μL	740361
LEGENDplex [™] Human IFN-α2 Capture Bead B3, 13X	1 vial	270 μL	741279
LEGENDplex™ Human IFN-λ2 Capture Bead B4, 13X	1 vial	270 μL	741277
LEGENDplex™ Human GM-CSF Capture Bead B5, 13X	1 vial	270 μL	740362
LEGENDplex™ Human IFN-β Capture Bead B6, 13X	1 vial	270 μL	741278
LEGENDplex [™] Human IL-10 Capture Bead B7, 13X	1 vial	270 μL	740358
LEGENDplex [™] Human IFN-γ Capture Bead B9, 13X	1 vial	270 μL	741280

Capture beads for Mix and Match Subpanels:

Please refer to Beads ID and Panel-Specific Target Selection table (Table 1), to see which capture beads are included in each panel.

LEGENDplex[™] Buffer Set I (Cat#: 740623)

Component	Quantity	Volume	Part #
Setup Beads: PE Beads	1 vial	1 mL	77842
Setup Beads: Raw Beads	1 vial	1.8 mL	77844
LEGENDplex [™] SA-PE	1 bottle	3.3 mL	77743
LEGENDplex [™] Matrix A, Lyophilized	1 vial	lyophilized	75306
LEGENDplex [™] Assay Buffer	1 bottle	25 mL	77562
LEGENDplex [™] Wash Buffer, 20X	1 bottle	25 mL	77564
Plate Sealers	4 sheets		78101

No plate is included in Buffer Set I. Plate need to be ordered separately. Please order the correct type of plate based on the preferred assay protocol (Cat# 740377 for Filter Plate and Cat# 740379 for V-bottom Plate)

Materials to be Provided by the End-User

• A flow cytometer equipped with two lasers (e.g., a 488 nm blue laser or 532 nm green laser and a 633-635 nm red laser) capable of distinguishing 575 nm and 660 nm or a flow cytometer equipped with one laser (e.g., 488 nm blue laser) capable of distinguishing 575 nm and 670 nm.

Flow Cytometer	Reporter Channel	Channel Emission	Classification Channel	Channel Emission	Compensa- tion needed?
BD Accuri [™] C6™	FL2	585 nm	FL4	675 nm	No*
BD FACSCanto, BD FACSCanto™II	PE	575 nm	APC	660 nm	No*
BD [™] LSR, LSR II BD LSRFortessa™	PE	575 nm	APC	660 nm	No*
Gallios™	PE	575 nm	APC	660 nm	No*
CytoFLEX	PE	585 nm	APC	660 nm	No*
NovoCyte	PE	572 nm	APC	660 nm	No*
Attune™ NxT	PE	574 nm	APC	670 nm	No*

Partial list of compatible flow cytometers:

*Compensation is not required for the specified flow cytometers when set up properly, but is recommended for consistent results.

For setting up the above flow cytometers, please follow the Flow Cytometer Setup guide in this manual or visit: www.biolegend.com/legendplex.

- Multichannel pipettes capable of dispensing 5 μ L to 200 μ L
- Reagent reservoirs for multichannel pipette
- Polypropylene microfuge tubes (1.5 mL)
- Laboratory vortex mixer
- Sonicator bath (e.g., Branson Ultrasonic Cleaner model #B200, or equivalent)
- Aluminum foil
- Absorbent pads or paper towels
- Plate shaker (e.g., Lab-Line Instruments model #4625, or equivalent)
- Tabletop centrifuges (e.g., Eppendorf centrifuge 5415 C, or equivalent)
- 1.1 mL polypropylene micro FACS tubes, in 96-tube rack (e.g., National Scientific Supply Co, catalog # TN0946-01R, or equivalent).

Human Anti-Virus Response Panel 1 Mix and Match Subpanel If the assay is performed in a filter plate:

- A vacuum filtration unit (Millipore MultiScreen[®] HTS Vacuum Manifold, cat # MSVMHTS00 or equivalent). Instructions on how to use the vacuum manifold can be found at the supplier's website.
- A vacuum source (mini vacuum pump or line vacuum, e.g., Millipore Vacuum Pump, catalog # WP6111560, or equivalent)
- If needed, additional Filter plates can be ordered from BioLegend (Cat# 740377 or 740378).

If the assay is run in a V-bottom plate:

- Centrifuge with a swinging bucket adaptor for microtiter plates (e.g., Beckman Coulter Allegra[™] 6R Centrifuge with MICROPLUS CARRIER adaptor for GH3.8 and JS4.3 Rotors).
- If needed, additional V-bottom plates can be ordered from BioLegend (Cat# 740379).

Precautions

- All blood components and biological materials should be handled as potentially hazardous. Follow universal precautions as established by the Center for Disease Control and Prevention and by the Occupational Safety and Health Administration when handling and disposing of infectious agents.
- Sodium azide has been added to some reagents as a preservative. Although the concentrations are low, sodium azide may react with lead and copper plumbing to form highly explosive metal azides. On disposal, flush with a large volume of water to prevent azide build-up.
- Do not mix or substitute reagents from different kits or lots. Reagents from different manufacturers should not be used with this kit.
- Do not use this kit beyond its expiration date.
- SA-PE and Beads are light-sensitive. Minimize light exposure.

Chapter 2: ASSAY PREPARATION

Sample Collection and Handling

Preparation of Serum Samples:

- Allow the blood to clot for at least 30 minutes and centrifuge for 10 minutes at 1,000 x g.
- Remove serum and assay immediately or aliquot and store samples at <-20°C. Avoid multiple (>2) freeze/thaw cycles.
- When using frozen samples, it is recommended that samples are thawed completely, mixed and centrifuged to remove particulates prior to use.

Preparation of Plasma Samples:

- Plasma collection using EDTA as an anti-coagulant is recommended. Centrifuge for 10 minutes at 1,000 x g within 30 minutes of blood collection.
- Remove plasma and assay immediately, or aliquot and store samples at <-20°C. Avoid multiple (>2) freeze/thaw cycles.
- When using frozen samples, it is recommended that samples are thawed completely, mixed well and centrifuged to remove particulates.

Preparation of Tissue Culture Supernatant:

• Centrifuge the sample to remove debris and assay immediately. If not possible, aliquot and store samples at ≤-20°C. Avoid multiple (>2) freeze/thaw cycles.

Reagent Preparation

Preparation of Antibody-Immobilized Beads:

- 1. The individual subpanels beads (13X) need to be combined with oneanother and diluted with Assay Buffer to create a 1X working solution of beads prior to use.
- 2. Sonicate each bead vial for 1 minute in a sonicator bath and then vortex for 30 seconds to completely resuspend the beads.
- 3. Calculate and prepare a 1X beads working solution based on the desired number of reactions and plex-size of your assay (i.e. the number of individual bead vials) following the steps described below.

A. Total volume (μ L) = 30 x (number of reactions)

B. Volume needed from each 13X beads vial (μ L) = 2.3 x (number of reactions)

C. Assay Buffer needed (μ L) = A – B x (number of individual beads vials to be mixed)

Note: calculations for total volume include a 20% excess to account for any loss during pipetting

Example: to prepare 50 reactions for a 5-plex assay

A. Total volume (μL) = 30 x 50 = 1500 μL

B. Volume per beads vial needed (μ L) = 2.3 x 50 = 115 μ L

C. Assay Buffer needed (µL) = A – B x (number of individual beads vials) =1500 – (115 x 5) = 925 µL

Combine 115 μ L of each beads vial (5 vials) with 925 μ L of assay buffer to get the desired final volume of 1500 μ L of 1X working solution of beads

Preparation of Wash Buffer

- Bring the 20X Wash Buffer to room temperature and mix to bring all salts into solution.
- Dilute 25 mL of 20X Wash Buffer with 475 mL deionized water. Store unused portions between 2°C and 8°C for up to one month.

Preparation of Matrix A (for Serum or Plasma Samples Only)

 Add 5.0 mL LEGENDplex[™] Assay Buffer to the bottle containing lyophilized Matrix A. Allow at least 15 minutes for complete reconstitution. Vortex to mix well. Leftover reconstituted Matrix A should be stored at ≤-70°C for up to one month.

Standard Preparation

- 1. Prior to use, reconstitute the lyophilized Human Anti-Virus Response Panel 1 Standard with 250 μL Assay Buffer.
- 2. Mix and allow the vial to sit at room temperature for 10 minutes, and then transfer the standard to an appropriately labeled polypropylene microcentrifuge tube. This will be used as the top standard C7.

Note: The top standard concentrations of analytes in this panel were set at various concentrations, but may be subject to change from lot to lot (please visit biolegend.com/en-us/legendplex to download a lot-specific certificate of analysis).

3. Label 6 polypropylene microcentrifuge tubes as C6, C5, C4, C3, C2 and C1, respectively.

- 4. Add 75 μ L of Assay Buffer to each of the six tubes. Prepare 1:4 dilution of the top standard by transferring 25 μ L of the top standard C7 to the C6 tube and mix well. This will be the C6 standard.
- 5. In the same manner, perform serial 1:4 dilutions to obtain C5, C4, C3, C2 and C1 standards (see the table below using the top standard at 10,000 pg/mL as an example). Assay Buffer will be used as the 0 pg/mL standard (C0).

Tube/ Standard ID	Serial Dilution	Assay Buffer to add (μL)	Standard to add	Final Conc. (pg/mL)*
C7				10,000
C6	1:4	75	25 µL of C7	2,500
C5	1:16	75	25 µL of C6	625
C4	1:64	75	25 µL of C5	156.3
C3	1:256	75	25 µL of C4	39.1
C2	1:1024	75	25 µL of C3	9.8
C1	1:4096	75	25 µL of C2	2.4
C0		75		0

Sample Dilution

• Serum or plasma samples must be diluted 2-fold with Assay Buffer before being tested (e.g. dilute 50 μL of sample with 50 μL of Assay Buffer).

If further sample dilution is desired, dilution should be done with Matrix A to ensure accurate measurement.

Adding serum or plasma samples without dilution will result in low assay accuracy and possibly, clogging of the filter plate.

• For cell culture supernatant samples, the levels of analyte can vary greatly from sample to sample. While the samples can be tested without dilutions, a preliminary experiment may be required to determine the appropriate dilution factor.

If sample dilution is desired, dilution should be done with corresponding fresh cell culture medium or Assay Buffer to ensure accurate measurement.

Chapter 3: ASSAY PROCEDURE

The LEGENDplex[™] assay can be performed either in a filter plate or in a V-bottom microplate.

- The in-filter assay procedure requires a vacuum filtration unit for washing (see Materials to be Provided by the End-User, page 8).
- If the Filter plate assay procedure is not possible or if you prefer, the assay can be performed in a V-bottom plate.

Performing the Assay Using a Filter Plate

- Allow all reagents to warm to room temperature (20-25°C) before use.
- Set the filter plate on an inverted plate cover at all times during assay setup and incubation steps, so that the bottom of the plate does not touch any surface. Touching a surface may cause leakage.
- Keep the plate upright during the entire assay procedure, including the washing steps, to avoid losing beads.
- The plate should be placed in the dark or wrapped with aluminum foil for all incubation steps.
- Standards and samples should be run in duplicate and arranged on the plate in a vertical configuration convenient for data acquisition and analysis (as shown in attached PLATE MAP, page 37). Be sure to load standards in the first two columns. If an automation device is used for reading, the orientation and reading sequence should be carefully planned.
- Pre-wet the plate by adding 100 µL of LEGENDplex[™] 1X Wash Buffer to each well and let it sit for 1 minute at room temperature. To remove the excess volume, place the plate on the vacuum manifold and apply vacuum. Do not exceed 10" Hg of vacuum. Vacuum until wells are drained (5-10 seconds). Blot excess Wash Buffer from the bottom of the plate by pressing the plate on a stack of clean paper towels. Place the plate on top of the inverted plate cover.

For measuring cell culture supernatant samples, load the plate as shown in the table below (in the order from left to right):

	Assay Buffer	Standard	Sample*
Standard Wells	25 μL	25 μL	
Sample wells	25 μL		25 μL

For measuring serum or plasma samples, load the plate as shown in the table below (in the order from left to right):


25	5μL	
5 μL ·	25 μl	
		25 με

*See Sample Dilution on page 12

- 2. Vortex mixed beads bottle for 30 seconds. Add 25 μ L of mixed beads to each well. The volume should be 75 μ L in each well after beads addition. (Note: During addition of the beads, shake mixed beads bottle intermittently to avoid bead settling).
- 3. Seal the plate with a plate sealer. To avoid plate leaking, do not apply positive pressure to the sealer when sealing the plate. Wrap the entire plate, including the inverted plate cover, with aluminum foil. Place the plate on a plate shaker, secure it and shake at approximate 500 rpm for 2 hours at room temperature.
- 4. Do not invert the plate! Place the plate on the vacuum manifold and apply vacuum as before in Step 1. Add 200 μ L of 1X Wash Buffer to each well. Remove Wash Buffer by vacuum filtration. Blot excess Wash Buffer from the bottom of the plate with an absorbent pad or paper towels. Repeat this washing step once more.
- 5. Add 25 µL of Detection Antibodies to each well.
- 6. Seal the plate with a fresh plate sealer. Wrap the entire plate, including the inverted plate cover, with aluminum foil. Place the plate on a plate shaker and shake at approximately 500 rpm for 1 hour at room temperature.
- **7.** Do not vacuum! Add 25 μL of SA-PE to each well directly.
- 8. Seal the plate with a fresh plate sealer. Wrap the entire plate, including the inverted plate cover, with aluminum foil. Place the plate on a plate shaker and shake at approximate 500 rpm for 30 minutes at room temperature.
- 9. Repeat step 4 above.
- 10. Add 150 μL of 1X Wash Buffer to each well. Resuspend the beads on a plate shaker for 1 minute.
- 11. Read samples on a flow cytometer, preferably within the same day of the assay (Note: Prolonged sample storage can lead to reduced signal).

If the flow cytometer is equipped with an autosampler, read the plate directly using the autosampler. Please be sure to program the autosampler to resuspend beads in the well immediately before taking samples. The probe height may need to be adjusted when using an autosampler.

If an autosampler is not available, the samples can be transferred from the filter plate to micro FACS (or FACS) tubes and read manually.



Performing the Assay Using a V-bottom Plate

- Allow all reagents to warm to room temperature (20-25°C) before use.
- Keep the plate upright during the entire assay procedure, including the washing steps, to avoid losing beads.
- The plate should be placed in the dark or wrapped with aluminum foil for all incubation steps.
- Standards and samples should be run in duplicate and arranged on the plate in a vertical configuration convenient for data acquisition and analysis (as shown in attached PLATE MAP, page 37). Be sure to load standards in the first two columns. If an automation device is used for reading, the orientation and reading sequence should be carefully planned.
- 1. For measuring cell culture supernatant samples, load the plate as shown in the table below (in the order from left to right):

	Assay Buffer	Standard	Sample*
Standard Wells	25 μL	25 μL	
Sample wells	25 μL		25 μL

For measuring serum or plasma samples, load the plate as shown in the table below (in the order from left to right):

	Matrix A	Assay Buffer	Standard	Sample*
Standard Wells	25 μL		25 μL	
Sample wells		25 μL		25 μL

*See Sample Dilution on page 12

- 2. Vortex mixed beads for 30 seconds. Add 25 μ L of mixed beads to each well. The total volume should be 75 μ L in each well after beads addition. (Note: During beads addition, shake mixed beads bottle intermittently to avoid bead settling).
- 3. Seal the plate with a plate sealer. Cover the entire plate with aluminum foil to protect the plate from light. Shake at 800 rpm on a plate shaker for 2 hours at room temperature (Depending on the shaker, the speed may need to be adjusted. The optimal speed is one that is high enough to keep beads in suspension during incubation, but not too high that it may cause sample to spill from the wells).
- Centrifuge the plate at 1050 rpm (~250 g) for 5 minutes, using a swinging bucket rotor (G.H 3.8) with microplate adaptor (Please refer to Materials to be Provided by the End-User, page 8). Do not use excessive centrifugation speed as it may make it harder to resuspend beads in later steps.

Make sure the timer of the centrifuge works properly and standby to make sure the centrifuge reaches preset speed.

5. Immediately after centrifugation, dump the supernatant into a biohazard waste container by quickly inverting and flicking the plate **in one continuous and forceful motion**. The beads pellet may or may not be visible after dumping the supernatant. Loss of beads should not be a concern as the beads will stay in the tip of the well nicely. Blot the plate on a stack of clean paper towel and drain the remaining liquid from the well as much as possible. Be careful not to disturb the bead pellet.


Alternatively, removal of the supernatant may be completed using a multichannel pipette set at 75 μ L. Try to remove as much liquid as possible without removing any beads. Be sure to change pipette tips between each row or column.

- 6. Wash the plate by dispensing 200 μ L of 1X Wash Buffer into each well and incubate for one minute. Repeat step 4 and 5 above. A second wash is optional, but may help reduce background.
- 7. Add 25 μ L of Detection Antibodies to each well.
- 8. Seal the plate with a new plate sealer. Cover the entire plate with aluminum foil to protect the plate from light. Shake at 800 rpm on a plate shaker for 1 hour at room temperature.
- **9.** Do not wash the plate! Add 25 μL of SA-PE to each well directly.
- 10. Seal the plate with a new plate sealer. Wrap the entire plate with aluminum foil and shake the plate on a plate shaker at approximate 800 rpm for 30 minutes at room temperature.
- 11. Repeat step 4 and 5.
- 12. (This washing step is optional but helps to reduce the background.) Wash the plate by dispensing 200 μL of 1X Wash Buffer into each well and incubate for one minute. Repeat step 4 and 5 above.
- 13. Add 150 μL of 1X Wash Buffer to each well. Resuspend the beads by pipetting.
- 14. Read samples on a flow cytometer, preferably within the same day of the assay (Note: Prolonged sample storage can lead to reduced signal).

If the flow cytometer is equipped with an autosampler, the samples can be read directly. Please be sure to program the autosampler to resuspend beads in the well immediately before taking samples. The probe height may need to be adjusted when using an autosampler.

If an autosampler is not available, the samples can be transferred from the plate to micro FACS (or FACS) tubes and read manually.

Assay Procedure Summary for V-bottom Plate



Chapter 4: FLOW CYTOMETER SETUP

In order to generate reliable data, the flow cytometer must be set up properly before data acquisition.

The setup instructions have been removed from this manual and uploaded onto our website to save paper.

To access the setup instructions, please visit: **www.biolegend.com/legendplex** and click on the **Instrument Setup** tab.

Chapter 5: DATA ACQUISITION AND ANALYSIS

Data Acquisition

- 1. Before reading samples, make sure that the flow cytometer is set up properly.
- 2. Create a new template or open an existing template (for details on how to create a cytometer-specific template, please refer to the Flow Cytometer Setup Guide).
- 3. Vortex each sample for 5 seconds before analysis.
- 4. Set the flow rate to low. Set the number of beads to be acquired to about 300 per analyte (e.g., acquire 900 beadsfor a 3-plex assay or 3,000 beadsfor a 10-plex assay). Do not set to acquire total events as samples may contain large amounts of debris. Instead, create a large gate to include both Beads A and Beads B (gate A+B) and set to acquire the number of events in gate A+B. This will exclude majority of the debris

Note: Do not acquire too few or too many beads. Too few beads acquired may result in high CVs and too many beads acquired may result in slow data analysis later.

5. Read samples.

When reading samples, set the flow cytometer to setup mode first and wait until bead population is stabilized before switching to acquisition mode.

To simplify data analysis using the LEGENDplex[™] Data Analysis Software, read samples in the same order as shown on the PLATE MAP attached at the end of the manual. For an in-plate assay, read column by column (A1, B1, C1...A2, B2, C2...).

When naming data files, try to use simple names with a consecutive numbering for easy data analysis (e.g. for standards, C0.001, C0.002, C1.003, C1.004, C2.005, C2.006, C3.007, C3.008, ... C7.015, C7.016; for samples, S1.017, S1.018, S2.019, S2.020, S3.021, S3.022...)

Store all FCS files in the same folder for each assay. If running multiple assays, create a separate folder for each assay.

6. Proceed to data analysis using LEGENDplex[™] Data Analysis Software when data acquisition is completed.


Data Analysis

• The assay FCS files should be analyzed using BioLegend's LEGENDplex[™] data analysis software. The program is offered free of charge with the purchase of any LEGENDplex[™] assay. For further information regarding acccess to, and use of the program please visit **biolegend.com/en-us/legendplex.**

Chapter 6: ASSAY CHARACTERIZATION

Standard Curve

This standard curve was generated using the LEGENDplex[™] Human Anti-Virus Response Panel 1 for demonstration purpose only. A standard curve must be run with each assay.



Assay Sensitivity

The lower limit of detection (LOD) is the theoretical limit of detection calculated using the LEGENDplexTM Data Analysis Software by applying a 5-parameter curve fitting algorithm. Assay sensitivity presented here is \leq Mean LOD + 2xSTDEV LOD.

Analyte	LOD in Cell Culture Medium (pg/mL)	LOD in Serum (pg/mL)
IFN-λ1 (IL-29)	2.3 + 3.9	8.0 + 10.2
IL-1β	1.1 +1.6	1.3 + 1.7
IL-6	0.8 + 1.3	1.0 + 1.3
TNF-α	0.9 + 0.8	1.1 + 1.5
IP-10	2.1 + 1.3	2.6 + 3.0
IL-8	0.5 + 0.4	0.7 + 1.0
IL-12p70	0.4 + 0.4	0.5 + 0.8
IFN-α2	1.0 + 1.6	0.8 + 1.4

IFN-λ2 (IL-28A)	2.3 + 3.5	3.0 + 6.8
GM-CSF	0.7 + 0.7	0.6 + 0.8
IFN-β	0.7 + 1.0	1.1 + 1.4
IL-10	0.5 + 0.5	0.7 + 1.1
IFN-γ	1.5 + 3.2	2.3 + 4.6

Cross-Reactivity

The following human recombinant proteins were tested at 10 ng/mL using the LEGENDplex[™] Human Anti-Virus Response Panel 1 V02. No or negligible cross-reactivity was found for all analytes.

IFN-λ1	IFN-α2	IFN-λ2	IFN-β	IFN-g	IL-1β	IL-6
IL-8	IL-10	IL-12p70	GM-CSF	IP-10	TNF-α	IFN-αD
IFN-α1	IL-13	IL-22	IL-15	IL-4	IL-17F	MCP-1
IL-23	IL-17A	MIP-1α	MIP-1β	Gro-α	ENA-78	Rantes
CXCL13	Eotaxin	IL-18	MIG	CCL1	CCL8	IL-27
CXCL12	CCL20	CCL21	CCL22	IL-21		

Accuracy (Spike Recovery)

For spike recovery in cell culture medium, RPMI or DMEM with 10% FCS were spiked with target proteins at three different levels within the assay range. The spiked samples were then assayed, and the measured concentrations were compared with the expected values.

For spike recovery in serum (n=8) and plasma (n=24), samples were first diluted two-fold with Assay Buffer and spiked with target proteins at three different levels within the assay range. The spiked samples were then assayed, and the measured concentrations were compared with the expected values.

Analyte	% of Recovery in RPMI	% of Recovery in DMEM	% of Recovery in Serum	% of Recovery in Plasma
IFN-λ1 (IL-29)	132%	119%	130%	100%
IL-1β	98%	95%	127	67%
IL-6	95%	92%	94%	64%
TNF-α	101%	94%	88%	50%
IP-10	102%	104%	60%	42%
IL-8	112%	101%	112%	59%
IL-12p70	98%	94%	95%	84%
IFN-α2	84%	82%	90%	64%
IFN-λ2 (IL-28A)	96%	94%	89%	67%
GM-CSF	105%	99%	96%	69%
IFN-β	89%	83%	90%	84%
IL-10	97%	94%	101%	87%
IFN-γ	101%	99%	106%	74%

Linearity of Dilution

For linearity in cell culture medium, 6 cell culture supernatant samples from stimulated PBMCs were serially diluted 1:2, 1:4, 1:8 with Assay Buffer and assayed. The measured concentrations of serially diluted samples were compared with that of the neat samples.

For testing linearity in serum (n=8) and plasma (n=24), samples were first diluted two-fold with Assay Buffer and spiked with a known concentration of target proteins. The spiked samples were serially diluted 1:2, 1:4, 1:8 with Matrix A and assayed. The measured concentrations of serially diluted samples were compared with that of the spiked samples.

Analyte	Linearity in Cell Culture Medium	Linearity in Serum	Linearity in Plasma
IFN-λ1 (IL-29)	99%	77%	132%
IL-1β	107%	113%	126%
IL-6	113%	133%	137%
TNF-α	111%	166%	199%

IP-10	111%	176%	183%
IL-8	103%	143%	158%
IL-12p70	114%	97%	129%
IFN-α2	110%	122%	125%
IFN-λ2 (IL-28A)	109%	126%	166%
GM-CSF	98%	139%	142%
IFN-β	102%	122%	124%
IL-10	112%	106%	110%
IFN-γ	102%	114%	134%

Intra-Assay Precision

Two samples with different concentrations of target proteins were analyzed in one assay with 16 replicates for each sample. The intra-assay precision was calculated as below.

Analyte	Sample	Mean (pg/mL)	STDEV	4%
IFN-λ1 (IL-29)	Sample 1	47.6	2.2	5%
IFIN-A1 (IL-29)	Sample 2	193.8	9.4	5%
ц 10	Sample 1	68.8	2.8	4%
IL-1β	Sample 2	254.3	10.2	4%
IL-6	Sample 1	55.8	4.0	7%
IL-0	Sample 2	212.7	14.1	7%
	Sample 1	88.1	4.1	5%
TNF-α	Sample 2	318.0	13.6	4%
IP-10	Sample 1	30.6	1.1	4%
IP-10	Sample 2	125.0	4.2	3%
IL-8	Sample 1	51.8	2.5	5%
IL-8	Sample 2	192.8	9.2	5%
1. 42. 70	Sample 1	51.4	2.3	5%
IL-12p70	Sample 2	191.3	11.0	6%
IFN-α2	Sample 1	55.4	2.5	4%
	Sample 2	211.5	12.6	6%

FN-λ2	Sample 1	124.7	6.3	5%
(IL-28A)	Sample 2	458.1	14.7	3%
GM-CSF	Sample 1	59.0	2.2	4%
GIVI-CSF	Sample 2	222.0	8.3	4%
IFN-β	Sample 1	46.5	2.8	6%
ГЕМ-р	Sample 2	167.8	8.3	5%
IL-10	Sample 1	67.2	2.9	4%
IL-10	Sample 2	248.6	11.7	5%
IFN-v	Sample 1	83.4	4.4	5%
ιειν-γ	Sample 2	292.8	11.9	4%

Inter-Assay Precision

Two samples with different concentrations of target proteins were analyzed in three independent assays with three replicates for each sample. The inter-assay precision was calculated as below.

Analyte	Sample	Mean (pg/mL)	STDEV	%CV
11 10	Sample 1	34.8	5.4	15%
IL-1β	Sample 2	165.4	27.3	16%
IL-6	Sample 1	48.3	6.9	14%
IL-0	Sample 2	216.1	37.3	17%
	Sample 1	36.8	6.8	18%
TNF-α	Sample 2	187.1	36.4	19%
IP-10	Sample 1	63.9	10.8	17%
19-10	Sample 2	269.7	46.0	17%
	Sample 1	23.3	4.1	18%
IFN-λ1 (IL-29)	Sample 2	167.0	32.4	19%
IL-8	Sample 1	32.0	6.1	19%
IL-8	Sample 2	169.1	30.7	18%
	Sample 1	34.8	5.6	16%
IL-12p70	Sample 2	170.2	30.8	18%
	Sample 1	52.2	10.2	19%
IFN-α2	Sample 2	194.1	35.8	18%

FN-λ2/3	Sample 1	134.3	20.9	16%
(IL-28A/B)	Sample 2	525.7	75.5	14%
GM-CSF	Sample 1	41.2	7.9	19%
GIVI-C3F	Sample 2	199.4	36.1	18%
	Sample 1	42.9	9.1	21%
IFN-β	Sample 2	177.1	28.4	16%
IL-10	Sample 1	49.1	8.2	17%
IL-10	Sample 2	216.9	38.1	18%
	Sample 1	58.1	10.6	18%
IFN-γ	Sample 2	265.2	42.7	16%

Biological Samples

Serum and Plasma

Normal human serum samples (n=18) were tested for endogenous levels of the proteins. The concentrations measured are shown below.

Analyte	Range (pg/ml)	% of Detectable	Mean (pg/mL)
IFN-λ1 (IL-29)	ND-171.6	69%	50.0
IL-1β	ND-58.7	63%	17.2
IL-6	ND-30.7	75%	7.8
TNF-α	ND-96.3	88%	16.9
IP-10	14.3-67.3	100%	31.7
IL-8	4.5-40.9	100%	18.4
IL-12p70	ND-21.1	75%	4.1
IFN-α2	ND-154.5	81%	35.4
IFN-λ2 (IL-28A)	ND-81.6	75%	29.2
GM-CSF	ND-30.4	63%	6.2
IFN-β	ND-71.7	81%	23.7
IL-10	ND-43.0	94%	6.6
IFN-γ	ND-74.7	81%	16.0

ND = Non-detectable

Normal human plasma samples (n=44) were tested for endogenous levels of proteins. The concentrations measured are shown below.

Analyte	Range (pg/mL)	% of Detectable	Mean (pg/mL)
IFN-λ1 (IL-29)	ND-134.9	82%	24.7
IL-1β	ND-30.3	48%	7.3
IL-6	ND-17.6	70%	5.9
TNF-α	ND-56.1	68%	8.3
IP-10	6.1-87.7	100%	23.7
IL-8	0.8-42.6	100%	6.3
IL-12p70	ND-25.1	73%	3.6
IFN-α2	ND-126.6	59%	22.6
IFN-λ2 (IL-28A	ND-231.3	89%	18.5
GM-CSF	ND-26.9	61%	5.6
IFN-β	ND-55.4	68%	14.0
IL-10	ND-77.9	89%	7.8
IFN-γ	ND-34.0	68%	11.0

ND = Non-detectable

Cell Culture Supernatant

Human PBMCs (1 x 10⁶ cells/mL) were cultured under various conditions (Unstimulated; LPS, 100 ng/mL; Poly I:C 50 μ g/mL; IFN- γ , 100 ng/mL primed for 2 hours + LPS, 1 μ g/mL; CL097, 2ug/mL). Supernatants were collected after 24 hours and assayed with the LEGENDplexTM Human Anti-Virus Response Panel 1. The results (all in pg/mL) are summarized below.

Analyte	Control	LPS	Poly IC	LPS+ IFN-γ	PBMC+ CL097
IFN-λ1 (IL-29)	3.8	15.3	14.5	32.5	38.7
IL-1β	1.0	1828.4	>12000	2592.2	>12000
IL-6	2.8	>10000	>10000	>10000	>10000
TNF-α	2.9	45.6	2873.7	3469.1	4898.0
IP-10	139.6	27.1	6.4	777.4	1437.3

IL-8	250.1	>10000	>10000	>10000	>10000
IL-12p70	0.4	1.9	2.5	114.2	7.2
IFN-α2	ND	4.0	2.4	3.7	207.8
IFN-λ2 (IL-28A)	1.3	13.0	8.4	14.1	21.2
GM-CSF	0.5	2.9	166.0	8.6	5.6
IFN-β	0.7	5.1	1.8	3.7	18.0
IL-10	1.0	1558.8	153.1	302.4	360.3
IFN-γ	ND	26.1	53.7	9479.8	1983.0

Human Anti-Virus Response Panel 1 Mix and Match Subpanel

ND = Non-detectable

TROUBLESHOOTING

Problem	Possible Cause	Solution
Bead popula- tion shifting upward or downward dur- ing acquisition	The strong PE signal from high concentra- tion samples or stan- dards may spill over to classification Channel (e.g., FL3/FL4/APC) and mess up the bead separation.	Optimize instrument settings using Kit Setup Beads, and make appropriate com- pensation between channels.
	Vacuum pressure is insufficient or vacuum manifold does not seal properly.	Increase vacuum pressure such that 0.2 mL buffer can be suctioned in 3-5 seconds. Clean the vacuum manifold and make sure no debris on the manifold. Press down the plate on the manifold to make a good seal.
		Centrifuge samples just prior to assay setup and use supernatant. If high lipid content is present, remove lipid layer after centrifugation. Sample may need dilution if too viscous.
Filter plate will	Samples have insoluble particles or sample is too viscous (e.g., serum and plasma samples)	If some wells are still clogged during wash- ing, try the following:
not vacuum or some wells clogged		1). Add buffer to all the wells, pipette up and down the clogged wells and vacuum again.
		2). Use a piece of clean wipe, wipe the un- der side of the clogged wells and vacuum again.
		3). Take a thin needle (e.g., insulin needle), while holding the plate upward, poke the little hole under each of the clogged wells and vacuum again. Do not poke too hard or too deep as it may damage the filter and cause leaking.
	Filter plate was used without pre-wet.	Pre-wet plate with wash buffer before run- ning the assay.

	Beads inappropriately prepared	Sonicate bead vials and vortex just prior to addition. Agitate mixed beads intermit- tently in reservoir while pipetting this into the plate.			
Insufficient bead count or slow reading	Samples cause beads aggregation due to particulate matter or viscosity.	Centrifuge samples just prior to assay setup and use supernatant. If high lipid content is present, remove lipid layer after centrifugation. Sample may need dilution if too viscous.			
Slow reading	Beads were lost during washing for in-tube assay	Make sure beads are spun down by visu- ally check the pellet (beads are in light blue or blue color). Be very careful when removing supernatant during washing.			
	Probe might be par- tially clogged.	Sample probe may need to be cleaned, or if needed, probe should be removed and sonicated.			
	Vacuum pressure set too high	Adjust vacuum pressure such that 0.2 mL buffer can be suctioned in 3-5 seconds. Do not exceed 10" Hg of vacuum.			
Plate leaked	Plate set directly on table or absorbent tow- els during incubations or reagent additions	Set plate on plate holder or raised edge so bottom of filter is not touching any surface.			
	Liquid present on the under side of the plate after vacuum	After washing, press down plate firmly on a stack of clean paper towels to dry the underside of the plate.			
	Pipette touching and damaged plate filter during additions.	Pipette to the side of wells.			
High Back-	Background wells were contaminated	Avoid cross-well contamination by chang- ing tips between pipetting when perform- ing the assay using a multichannel pipette.			
ground	Insufficient washes	The background may be due to non- specific binding of SA-PE. Increase number of washes.			
Debris (FSC/ SSC) during sample acquisi- tion	Debris or platelet may exist in sample solu- tion.	Centrifuge samples before analyzing samples. Remove platelet as much as possible.			

	1				
Variation be-	Beads aggregation	Sonicate and vortex the Beads prior to use.			
	Multichannel pipette may not be calibrated or inconsistent pipet- ting	Calibrate Pipette. Ensure good pipetting practice. Prime pipette before use may help.			
tween duplicate samples	Plate washing was not uniform	Make sure all reagents are vacuumed out completely in all wash steps.			
	Samples may contain particulate matters.	Centrifuge samples just prior to assay setup and use supernatant. If high lipid content is present, remove lipid layer after centrifugation. Sample may need dilution if too viscous.			
Low or poor standard curve	The standard was in- correctly reconstituted, stored or diluted	Follow the protocol to reconstitute, store and dilute standard. Double check your calculation.			
signal	Wrong or short incuba- tion time	Ensure the time of all incubations was appropriate.			
Signals too high, standard curves satu-	PMT value for FL2/PE set too high	Make sure the PMT setting for the re- porter channel is appropriate			
rated	Plate incubation time was too long	Use shorter incubation time.			
	Samples contain no or below detectable levels of analyte	Make sure the experiment to generate the samples worked. Use proper positive controls.			
Sample read- ings are out of range	Samples concentrations higher than highest standard point.	Dilute samples and analyze again.			
	Standard curve was saturated at higher end of curve.	Make sure the PMT setting for the re- porter channel is appropriate. Use shorter incubation time if incubation time was too long			
Missed beads populations during reading, or distribution	Sample may cause some beads to ag- gregate.	Centrifuge samples just prior to assay setup and use supernatant. If high lipid content is present, remove lipid layer after centrifugation. Sample may need dilution if too viscous.			
is unequal	Beads populations are not mixed properly	Make sure all bead populations are mixed. and in similar numbers.			

PLATE MAP (for in-plate assay)

12	e Sample 37	e Sample 37	e Sample 38	e Sample 38	e Sample 39	e Sample 39	e Sample 40	
11	Sample 33	Sample 33	Sample 34	Sample 34	Sample 35	Sample 35	Sample 36	
10	Sample 29	Sample 29	Sample 30	Sample 30	Sample 31	Sample 31	Sample 32	
6	Sample 25	Sample 25	Sample 26	Sample 26	Sample 27	Sample 27	Sample 28	
8	Sample 21	Sample 21	Sample 22	Sample 22	Sample 23	Sample 23	Sample 24	
7	Sample 17	Sample 17	Sample 18	Sample 18	Sample 19	Sample 19	Sample 20	
6	Sample 13	Sample 13	Sample 14	Sample 14	Sample 15	Sample 15	Sample 16	
5	Sample 9	Sample 9	Sample 10	Sample 10	Sample 11	Sample 11	Sample 12	
4	Sample5	Sample5	Sample6	Sample6	Sample7	Sample7	Sample8	
œ	Sample1	Sample1	Sample2	Sample2	Sample3	Sample3	Sample4	
2	C4	C4	C5	C5	CG	CG	C7	
1	CO	CO	CI	C1	7	C2	ប	
	۷	В	U	D	ш	ш	U	İ

BioLegend®

LEGENDplex[™] Kits are manufactured by **BioLegend** 8999 BioLegend Way San Diego, CA 92121 Tel: 1.858.768.5800 Tel: US & Canada Toll-Free: 1.877.Bio-Legend (1.877.246.5343) Fax: 1.877.455.9587 Email: info@biolegend.com biolegend.com

For a complete list of world-wide BioLegend offices and distributors, please visit our website at: biolegend.com

741269-741270M_R2